

**Price  
List of  
Parts**

*Ford Model T*

**In effect July 1st 1911**

POSTAGE

**2<sup>C</sup>**

# **Price List of Parts—Ford Model T**

*Ford Motor Company*

Main Factory and General Offices  
DETROIT, U. S. A.

BRANCHES

ATLANTA  
311 Peachtree Street

BOSTON  
147 Columbus Avenue

BUFFALO  
1048 Main Street

CAMBRIDGE  
195 Massachusetts Avenue

CHICAGO  
1444 Michigan Avenue

CINCINNATI  
911 Race Street

CLEVELAND  
4400 Euclid Ave.

DALLAS  
1915 Commerce Street

DENVER  
1552 Broadway

DETROIT  
1550 Woodward Avenue

FARGO  
17 Broadway

FOREIGN DEPT.  
18 Broadway, N. Y.

HOUSTON  
800 Walker Avenue

INDIANAPOLIS  
526 North Capitol Avenue

KANSAS CITY  
1608 Grand Avenue

LONDON  
57 Shaftesbury Avenue

NEW YORK  
1723 Broadway

OMAHA  
1916 Harney Street

PARIS  
144 Boulevard Pereire

PHILADELPHIA  
250 N. Broad Street

PITTSBURG  
5925 Baum Street

ST. LOUIS  
3667 Olive Street

SEATTLE  
532 19th Avenue, North

Canadian Trade Supplied by

The FORD MOTOR CO., of Canada, Limited  
WALKERVILLE, ONTARIO

HAMILTON  
128 King St. West

MELBOURNE  
103 William Street

MONTREAL  
7 Park Avenue

TORONTO  
106 Richmond St.

WINNIPEG  
309 Cumberland Avenue






**2 Passenger Open Runabout**

# Instructions For Ordering Parts

---




**2 Passenger Torpedo Runabout**

- 1.** Order all parts through the nearest Branch or Dealer representing us in your territory, as parts are generally carried in stock by them.
- 2.** Specify model, and give number and name of each part ordered, as well as the machine number.
- 3.** Cash should accompany all orders. If it is desired to have parts shipped C. O. D., a deposit sufficient to cover transportation charges must be remitted with the order.
- 4.** Mail orders must be accompanied by an amount sufficient to cover postage.
- 5.** All prices are net f. o. b. Detroit.
- 6.** Specify whether shipments are to be forwarded by mail, express or freight.
- 7.** Orders for parts should be written separately from correspondence pertaining to other matters, as this will insure prompt handling by the proper department at the factory.



**2 Passenger Coupe**



**5 Passenger Touring Car**



**6 Passenger Town Car**

# Telegraph Code

**T**O save expense, to expedite ordering and for the convenience of those ordering parts, we have arranged a code word for each part of the Model "T" car. In addition to the parts code we list below a brief general code covering miscellaneous instruction, questions and answers relative to the entering and shipping of parts ordered.

¶ In telegraphing an order for parts start with the code telling us how to ship, then use the word for the next part, stating the number required and then give the number of your car.

¶ The following will illustrate how to send in an express order for 8 push rods No. 3058, 1 fan No. 496, and 3 transmission band springs No. 3425:

FORD MOTOR COMPANY,  
Detroit, Mich.

Toperig, eight Tubgener, one Tuburbain, three Tubmergin for car No. 2841.

Signed \_\_\_\_\_


**Toperig** Ship to me (us) by express.  
**Toperkleur** Ship by express to  
**Topermolen** Ship to me (us) by American Express  
**Toperoker** Ship to me (us) by U. S. Express  
**Toperpool** Ship to me (us) by Dominion Express  
**Topersteen** Ship to me (us) by freight  
**Toper** Ship to me (us) by mail  
**Topfton** When and how did you ship parts called for in my (our) telegram of—

**Topflutch** When and how will you ship parts called for in my (our) telegram of—  
**Topfwasser** When and how will you ship parts called for in my (our) letter of—  
**Topfgeld** Cancel order for parts our (my) telegram of—  
**Topfgicht** Cancel order for parts my (our) letter of—  
**Topfkiemer** Add to our (my) telegraph order of—  
**Topfartig** Will send duplicate shipment by—express at once.  
**Topfhaar** Will send duplicate order—freight at once.

When writing messages in code, print the code words in capital letters.



Rear Axle 56" Tread



Order by these Nos.	Description	Factory No.	Price.	Code Word.
2500	Rear axle assembly	95E	\$100 00	Tubial
2501	Axle housing right (drilled for 1/2" stud No. 2584)	1B	16 00	Tuability
2501 1/4	Axle housing right (drilled for 13/32" stud No. 2584 1/2)	1E	16 00	Tuabol
2502	Axle housing left (drilled for 1/2" stud No. 2584)	2B	16 00	Tuadebant
2502 1/4	Axle housing left (drilled for 13/32" stud No. 2584 1/2)	2E	16 00	Tuadero
2503A	Axle housing bolt (9/16" long)	42A	05	
2503B	Axle housing bolt (25/32" long)	42B	05	
2503C	Axle housing bolt (1-1/16" long)	42C	05	
2503D	Axle housing bolt (1-7/8" long)	157	05	
2504	Axle housing bolt nut	44	02	Tuadlals
2505	Axle shaft (Gear secured by double key and pin)	48	2 50	Tuadibale
2505 1/2	Axle shaft (Gear secured by large key and collar)	48B	2 50	Tuadonor
2506	Axle shaft washer (fibre)	39	05	Tuadinas
2507	Axle shaft babbitt bearing	51	80	Tuadibil
2508	Axle shaft roller bearing	97	1 00	Tuadibox
2509	Axle shaft R/B sleeve	170	40	Tuadiega
2510	Axle housing cap	56	10	Tuadicut
2510 1/4	Axle outer R/B steel washer	199	05	Tuadio
2510 1/2	Axle outer R/B felt washer	104	05	Tuadin
2511	Differential assembly		30 00	Tuadiera
2512	Differential case—left (Machined for 9/16" spider arms)	10B	5 00	Tuadirect
2512 1/2	Differential case—left (Machined for 1/2" spider arms)		5 00	
2513	Differential case—right (Machined for 9/16" spider arms)		4 00	
2513 1/2	Differential case—right (Machined for 1/2" spider arms)		4 00	
2514	Differential case stud	52	10	Tuadistes
2515	Differential case stud nut	53	05	Tuadora
2517	Differential case bushing (bronze)	19	80	Tuair
2518	Differential drive gear—40 teeth (Specify whether gear is fastened with screws or rivets)	12B	8 00	Tuandobil
2519	Differential drive gear screw	103	02	Tuadones
2519 1/4	Differential gear collar		05	
2520	Differential gear (fastened to shaft with double key and pin)	13	2 50	Tuarismo
2520 1/2	Differential gear (fastened to shaft with large key and collar)	13B	2 50	Tuarla
2521	Differential gear key (for gear 2520)	21B	10	Tuarista
2521 1/4	Differential gear key (for gear 2520 1/4)	36	10	Tuasible
2522	Differential gear pin		05	
2523	Differential gear thrust washer (fibre)	32	15	Tuasion
2524	Differential pinion—12 teeth ... Diameter bushing 9/16	14	1 25	Tuasive
2524 1/2	Differential pinion (Dia. bushing 5/8)		1 25	
2525	Differential pinion bushing (9/16)		25	Tuasively
2525 1/4	Differential pinion bushing (1/2)		25	
2526	Differential spider with bushing (dia. arms 9/16)	15	2 00	Tuasoribis
2526 1/2	Differential spider with bushing (dia. arms 5/8)		2 00	

Plate 1—Rear Axle Parts



Rear Axle—Continued

Order by these Nos.	Description	Factory No.	Price.	Code Word.
2527	Differential spider bushing	18	40	Tuasso
2528	Differential thrust plate washer (babbitt)	30	50	Tuastene
2529	Differential thrust plate (steel)	31	20	Tuavely
2530	Differential thrust plate pin (13/32" long)	17	05	Tuavement
2531	Differential thrust plate pin (7/32" long)	37	05	Tuaveolen
2532	Differential housing oil plug	817	05	Tuaveolus
2534	Drive shaft and R/A housing stud (1 1/4" long)	23	05	Tuavident
2535	D/S and R/A housing stud nut	8	05	Tuavidico
2539	D/S housing rear bushing (specify bore)	24C	1 00	Tuavignor
2540	D/S housing front bushing	69	60	Tuaviox
2541	D/S with pinion (specify diameter at rear bushing end)	154	8 00	Tuavitate
2542	Drive shaft only (specify diameter at rear bushing end)	37	3 50	Tuaviza
2543	D/S pinion—11 teeth	16	4 50	Tuavizde
2544	D/S pinion key (Woodruff)	57	10	Tuavizamo
2545	D/S grease cup	195B	25	Tuavizape
2545 1/2	Rear axle grease cup		15	
2546	D/S thrust washer (steel)	22B	15	Tuavizent
2547	Rear radius rod	152	2 50	Tuavizora
2548	Radius rod nut	77	05	Tuavizon
2549	Radius rod lock nut	78	05	Tuavizqua
2551	Radius rod bolt	83	05	Tubaccusa
2554	Ball joint support bolt	79	05	Tubacques
2555	Ball joint support bolt nut	80	05	Tubacribu
2557	Hub cam shaft—right	92F	30	Tubact
2558	Hub cam shaft—left	61B	30	Tubactaro
2559	Hub cam shaft bushing	173	20	Tubaction
2560	Hub brake spring	63	05	Tubactrom
2561	Hub spring rivet, per doz.	64	05	Tubadjuva
2562	Cam shaft lever	62	30	Tubadjuz
2563	Cam shaft lever pin	7	02	Tubadmovo
2564	Lever clevis pin	65	02	Tubagregro
2565	Lever clevis pin cotter	66	01	Tubagrest
2566	Brake shoe (cast iron)	55	75	Tubading
2567	Brake shoe support bolt	59	05	Tubaile
2568	Brake shoe support nut	60	05	Tubalar
2570	Brake shoe coil spring	67	05	Tubalhens
2571	Universal joint assembly	151	2 75	Tubalbid
2572	Joint knuckle (male)	45B	1 00	Tubalboat
2573	Joint knuckle (female)	46B	1 00	Tubalbay
2574	Joint knuckle pin	6	05	Tubalbala
2575	Joint ring complete	49	75	Tubalcaid
2576	Joint ring rivets, each	50	05	Tubalkins
2577	Joint housing	70	1 00	Tubaltenu
2578	Joint housing plug	75	05	Tubambige
2579	Ball cap oil hole plug	156	10	Tubambros
2580	Ball cap felt gasket	1518	10	Tubamigue

Drive Shaft Assembly

2581	D/S housing assembly (drilled for 3/8" stud)		14 00	Tubarnn
2581 1/2	D/S housing assembly (drilled for 13/32" stud)		14 00	
2582	D/S housing (drilled for 3/8" stud)	74C	8 00	Tubarnno
2582 1/2	D/S housing (drilled for 13/32" stud)	74D	8 00	
2583	D/S roller bearing housing (drilled for 3/8" stud)	191	1 00	Tubamla




Plate 2—Roller Bearing Drive Shaft Parts






Plate 3—Front Axle Parts

Drive Shaft Assembly—Continued

Order by these Nos.	Description	Factory No.	Price.	Code Word.
2583½	D/S roller bearing housing (drilled for 13/32" stud).....	191B	1 00	
2584	D/S roller bearing stud (¾" x 4-7/16") .....	183	10	Tubamlen
2584½	D/S roller bearing stud (13/32" x 4½") .....	183B	10	
2585	D/S roller bearing housing stud nut (¾") .....	184	02	Tubamhue
2585½	D/S roller bearing housing stud nut (13/32") .....	184B	02	
2586	D/S roller bearing housing set screw .....	101	05	Tubamdent
2587	D/S roller bearing .....	192	2 50	Tubamaub
2588	D/S roller bearing distance plate .....	106	10	Tubamging
2589	D/S ball race .....	186	60	Tubamgu
2590	D/S ball retainer .....	190	05	Tubamgone
2591	D/S ball thrust collar .....	188	30	Tubamg
2592	D/S ball bearings (15) each .....	187	04	Tubamy
2593	D/S roller bearing sleeve .....	107	50	Tubameny
2594	D/S and pinion .....	154B	8 00	Tubamly
2595	D/S with sleeve fitted (straight shaft) .....			
		87C	3 50	Tubamend
2595½	D/S only (tapered end) .....	87D	3 00	
2595½	D/S with sleeves and ball bearing assembly .....		4 00	
2595¾	D/S with pinion and ball bearing assembly .....		8 00	
2596	D/S sleeve .....	163B	50	Tubamfore
2597	D/S pinion (¾" straight bore) .....	16B	4 50	Tubambin
2597½	D/S pinion (for tapered shaft) .....	16C	4 50	
2598	D/S castle nut .....	124	15	

Rear Axle 60" Tread

2599	Rear axle assembly (roller bearing type) .....	1727C	100 00	Tubamis
2600	Rear axle housing—right (drilled for ¾" stud No. 2584) .....	1701D	16 00	Tubamit
2600½	Rear axle housing—right (drilled for 13/32" stud No. 2584½) .....	1701E	16 00	Tubamil
2601	Rear axle housing—left (drilled for ¾" stud No. 2584) .....	1702D	16 00	Tubamore
2601½	Rear axle housing—left (drilled for 13/32" stud No. 2584½) .....	1702E	16 00	Tubamor
2602	Rear axle shaft (33" long; gear secured by double key and pin) .....	1703	2 50	Tubamoty
2602½	Rear axle shaft (33" long; gear secured by large Woodruff key and collar) .....	1703B	2 50	Tubant
2604	Rear radius rod .....	1725	2 50	Tubantully
2605	Hub brake pull rod—right .....	1710B	45	Tubapantó
2606	Hub brake pull rod—left .....	1721	45	TuhapeghT

Front Axle 56" Tread

2690	Front axle assembly .....	261B	24 00	Tubapenit
2691	Front axle only .....	202B	8 00	Tubapent
2694	Spindle body—right .....	203B	2 50	Tubapor
2695	Spindle body—left .....	204B	2 50	Tubapil
2696	Spindle arm .....	270	1 00	Tubapan
2697	Spindle arm nut .....	272	10	Tubapano
2702	Spindle assembly—right .....	203A	3 50	Tubaperes
2703	Spindle assembly—left .....	204A	3 50	Tubaperis
2704	Stationary cone (inside) .....	205	30	Tubapallt
2705	Adjusting cone—right thread .....	206	25	Tubaquat



Front Axle 56" Tread—Continued

Order by these Nos.	Description	Factory No.	Price.	Code Word.
2706	Adjusting cone—left thread	207	95	Tubaqueos
2707	Spindle nut—right thread	208B	10	Tubaquilo
2708	Spindle nut—left thread	209B	10	Tubaquilo
2709	Spindle washer	210	05	Tubarabun
2710	Spindle bolt	211B	50	Tubarando
2711	Spindle bolt nut	212	05	Tubarator
2713	Spindle body bushing (pair)	223	50	Tubaradust
2714	Spindle arm bushing	225	20	Tubarosa
2715	Spindle oiler	218	15	Tubaresco
2716	Spindle connecting rod with yoke	264	2 60	Tubarmale
2717	Spindle con. rod with ball pin only	268	2 00	Tubasper
2718	Spindle con. rod bolt (2-7/16")	216	05	Tubassam
2719	Spindle con. rod bolt nut	231	05	Tubasese
2721	Spindle con. rod yoke	248	60	Tubastam
2722	Steering yoke clamp bolt (1-5/32" long)	250	05	Tubastane
2723	Steering yoke clamp bolt nut	251	02	Tubastape
2725	Steering gear con. rod only (1/2" x 20 th'd)	258	30	Tubastsi
2725 1/4	Steering gear con. rod only (1/2" x 13 th'd)	258B	30	Tubasta
2726	Ball socket assembly	266	1 00	Tubastato
2726 1/2	Ball socket assembly (for 2725 1/4)	288B	1 00	Tubsta
2727	Ball socket	253	50	Tubastava
2727 1/2	Ball socket (for 2725 1/4)	253B	50	Tubtas
2728	Ball socket cap	254B	20	Tubasto
2729	Ball socket bolt	255	05	Tubastral
2730	Ball socket nut	256	03	Tubaud
2732	Ball socket lock nut (20 th'd)	259A	05	Tubaurabs
2732 1/4	Ball socket lock nut (13 th'd)	259B	05	Tubaubs
2733	Front radius rod	263	4 00	Tubaurad
2734	Front radius rod nut	245	05	Tubaurtos
2736	Front radius ball cap	217	20	Tubauster
2738	Front radius rod ball cap screw (1/2"—24 th'd)	210	05	Tubbajlas
2739	Front radius rod ball cap screw (1/2"—16 th'd)	210B	05	Tubaj

Front Axle 60" Tread

2760	Front axle only	1720B	8 00	Tubazit
2761	Steering spindle connecting rod	1725	2 60	Tubbajnon
2762	Steering gear con. rod only	1719	30	Tubbajtoz

Wheels

2800	Front wheel—red	291	8 00	Tubbaec
2801	Front wheel—green	291	8 00	Tubbaden
2802	Front wheel (Specify Pearl or French gray)	291	8 00	Tubbagrot
2802 1/2	Front wheel—blue	291	8 00	Tubbagoat
2803	Front hub assembly (1909-10 type)	200	6 00	Tubbalas
2804	Outer race (small)	234	50	Tubbalba
2805	Inner race (large)	235	60	Tubbame
2806	Outer ball retainer	236	10	Tubbanous
2807	Inner ball retainer	237	10	Tubbabante
2808	Dust ring (steel)	238	25	Tubbaste
2809	Felt washer	239	05	Tubbalano
2810	Large balls (1 1/4")	241	05	Tubbiase
2811	Small balls (3/4")	249	04	Tubblavan
2812	Rear wheel—red	99	8 00	Tubbibets
2813	Rear wheel—green	99	8 00	Tubbicac
2814	Rear wheel (Specify Pearl or French gray)	99	8 00	Tubbidado




Plate 4 Wheels and Parts






Plate 5—Frame, Fender and Tank Parts

Wheels—Continued

Order by these Nos.	Description	Factory No.	Price.	Code Word.
2814 <sup>1/2</sup>	Rear wheel—blue .....	99	8 00	Tubbidonor
2815	Rear hub (1909-10 type) .....	102	5 00	Tubbibims
2816	Rear hub key .....	26	05	Tubbiho
2817	Rear hub pin .....	27	02	Tubbihent
2818	Rear hub brake drum .....	3	1 00	Tubbiello
2819	Hub cap .....	240	60	Tubbisato
2820	Hub bolt (2" x 5/16") .....	28A	05	Tubbracha
2821	Hub bolt nut (5/16"—18 th'd) ..	29A	02	Tubbrado
2822	Hub flange (5 1/2" dia.) .....	233A	60	Tubbrevia
2823	Front hub assembly (1911 type) ..	200B	6 00	Tubbalas
2824	Rear hub assembly (1911 type) ..	102B	5 00	Tubbibims
2825	Hub bolt (2 x 3/8") .....	28B	05	Tubbrach
2826	Hub bolt nut (3/8"—18 th'd) .....	29B	02	Tubrad
2827	Hub flange (6" dia.) .....	233B	60	Tubrev

Frame

2850	Frame assembly .....	300	15 00	Tubcandid
2851	Side member—right .....	301	5 00	Tubacarre
2852	Side member—left .....	302	5 00	Tubaudal
2853	Front cross member .....	303	2 50	Tubcaute
2854	Rear cross member .....	304	2 50	Tubcaurn
2855	Front corner bracket—right .....	305	50	Tubcavabo
2856	Front corner bracket—left .....	306	50	Tubcava
2857	Rear corner bracket—right .....	307	50	Tubcaves
2858	Rear corner bracket—left .....	308	50	Tubcaveux
2863	Body bracket (on frame) .....	344	15	Tubcentda
2864	Side member—left (Runabout) .....	363	5 00	
2865	Side member—right (Runabout) ..	334	5 00	

Runabout—Gasoline Tank

2875	Gasoline tank (16 1/2 gals.) .....	1990	10 00	Tubcal
2876	Filler cap .....	2315	30	Tubcar
2877	Sediment bulb .....	2341	30	Tubcane
2878	Feed pipe .....	1394	40	Tubcasse
2879	Feed pipe clip .....	1395	05	Tubcam
2880	Tank bolt (5/16 x 2 1/2") .....	2345	05	Tubcat
2881	Tank bolt nut .....	2347	03	Tubca
2882	Tank bolt washer .....	2346	01	Tubces
2883	Tank stop cock .....	1343	35	Tubcer

Touring Car—Gasoline Tank

2900	Gasoline tank (10 gals) .....	1303	4 00	Tubcerna
2901	Filling plug .....	1317	30	Tubcerno
2902	Sediment bulb .....	1319	35	Tubcernut
2903	Tank bolt (25/32" long) .....	1320	05	Tubclavio
2904	Tank bolt (29/32" long) .....	1323	05	Tubcomnun
2905	Tank bolt nut .....	1321	03	Tubconque
2907	Stop cock .....	1343	35	Tubconsay
2908	Pet cock .....	1342	25	Tubcontin
2909	Feed pipe .....	1364	40	Tubcoqxues
2910	Feed pipe pack nut .....	1374	05	Tubcoquo

Fenders 56" Tread

2925	Front fender—left (round extension cap front end) specify color .....	1413	4 00	Tubcorted
2926	Front fender—right (round extension cap front end) specify color .....	1414	4 00	Tubcortex
2927	Rear fender—left (with hole in apron for fender iron) specify color .....	1415B	3 50	Tubcosyn



## Fenders—Continued

Order by these Nos.	Description	Factory No.	Price	Code Word
2927½	Rear fender—left (without hole in apron for fender iron) specify color .....	1415	3 50	Tubcortom
2928	Rear fender—right (with hole in apron for fender iron) specify color .....	1416B	3 50	Tubeoyter
2928½	Rear fender—right (without hole in apron for fender iron) specify color .....	1416	3 50	Tubcostal
2929	Front fender iron (right or left) .....	343	1 00	Tuberania
2930	Rear fender iron (right) .....	342B	1 50	Tubercrowd
2931	Rear fender iron (left) .....	349B	1 50	Tuberoylet
2932	Fender iron bolt (29/32" long) ..	345	05	Tubcruned
2933	Fender iron bolt (1-1/82" long) ..	347	05	Tubcrnot
2934	Fender iron bolt nut .....	346	03	Tubcanald
2935	Fender eye bolt .....	1942	15	Tubcnozr
2936	Fender eye bolt washer .....	1943	03	Tubcunab
2937	Fender eye bolt nut .....	1944	03	Tubcunuth

## Running Board 56" Tread


2941	Running board (Pressed steel) ..	1410B	1 00	Tubcunatt
2942	Running board metal shield—left .....	1408	2 50	Tubcurvos
2943	Running board metal shield—right .....	1409	2 50	Tubcustos
2944	Running board fender bolt .....	1944	05	Tubcullie
2945	Running board fender bolt nut ..	1347	02	Tubdehous
2946	Running board bracket .....	336	75	Tubdeacana
2947	Running board truss rod (front) ..	338	40	Tubdecupe
2947½	Running board truss rod (rear) ..	371	40	Tubdecup
2948	Running board truss rod nut .....	339	02	Tubdefend
2949	Running board bolt .....	340B	05	Tubdegnoy
2950	Running board bolt nut .....	341	02	Tubdelero
2951	Running board fender bolt washer .....	1959	03	Tubdeloth
2952	Running board metal shield for Town Car (left) .....	1731	2 50	Tubdelom
2953	Running board metal shield for Town Car (right) .....	1732	2 50	Tubdelore

## Fenders and Running Boards 60" Tread

3875	Front fender—right .....	1715	4 00	Tubdelta
3876	Front fender—left .....	1716	4 00	Tubdelsog
3877	Front fender iron (right and left) ..	1713	1 00	Tubdening
3878	Rear fender iron—left .....	1711	1 50	Tubdentick
3879	Rear fender iron—right .....	1712	1 50	Tubdentory
3880	Running board metal shield—right .....	1717	2 50	Tubfrplyc
3881	Running board metal shield—left ..	1718	2 50	Tubdegrin
3882	Running board brackets, each .....	1714	75	Tubdercip
3883	Running board truss rods, each .....	1708	40	Tubdestirn
3884	Running board metal shield for Town Car—right .....	1732	2 50	
3885	Running board metal shield for Town Car—left .....	1731	2 50	

## Running Boards

(Used on cars numbered below 2500).				
1410	Running board complete—right ..		4 00	Tubcurrote
1411	Running board complete—left .....		4 00	Tubcurral
1412	Running board rubber matting .....		1 00	Tubcurrod
1421	Running board brass (rear end) .....		30	Tubcutano
1422	Running board brass (left outside) .....		75	Tubcamus
1423	Running board brass (front end) ..		30	Tubdeacon
1424	Running board brass screw .....		01	Tubdeales
1425	Running board brass (right outside) .....		75	Tubdealbo







Running Boards—Continued

Order by these Nos.	Description	Factory No.	Price.	Code Word.
1486	Running board brass (left outside)		75	Tubdean
1487	Running board brass (right inside)		75	Tubdeary
1488	Running board brass screw (1/2 inch)		01	Tubdehamus
1344	Running board fender bolt		05	Tubdebble
1347	Running board fender bolt nut		02	Tubdeboous
340	Running board bolt		05	Tubdela

Motor (Thermo-Syphon)

3000	Cylinder with valve covers	400B	24 00	Tubdiat
3001	Cylinder head	401C	4 00	Tubdianon
3001 1/2	Cylinder head for metric thread foreign spark plug			
3002	Cylinder head copper gasket	402B	75	Tubdiboul
3003	Cylinder head cap screw (7/16 x 2-7/16")	483B	05	Tubdicken
3003 1/2	Cylinder head cap screw		05	
3004	Cylinder head outlet connection	446C	25	Tubdictol
3005	Cylinder head outlet connection copper gasket			
3006	Cylinder head outlet hose (3 1/4" long x 2" inside)	445B	15	Tubdidrom
3007	Cylinder head outlet hose clip	448B	30	Tubdfenez
3008	Cylinder head outlet connection screw (1-21/64" long)	607B	10	Tubdfindo
		550C	05	Tubdigitor
3009	Cylinder cover (front end)	403B	1 25	Tubdivory
3010	Cylinder cover bolt (13/16" long)	589	05	Tubdllosty
3011	Cylinder cover cap screw	432	05	Tubdlmida
3012	Cylinder cover felt	504	10	Tubdltasm
3013	Cylinder cover paper liner	505B	05	Tubdlteck
3014	Cylinder cover bolt (1-7/32" long)	484	05	Tubdltoit
3015	Cylinder water inlet connection (cast iron)	442B	25	Tubditoyer
3016	Cylinder water inlet connection screw (1 1/2" long)	597	05	Tubditunck
3018	Cylinder water inlet gasket	596	15	Tubdluray
3019	Cylinder water jacket plug	557	10	Tubdlvid
3020	Piston complete (3 ring type)	586B	2 50	Tubdlxons
3021	Piston only (3 ring type)	418C	2 00	Tubdlxyert
3022	Piston pin	419B	50	Tubdlzolt
3022 1/4	Piston Pin Bushing (2 pcs.)		30	
3023	Piston ring	422	17	Tubdcoctor
3024	Connecting rod (no bushing in upper end)	587B	2 50	Tubdodder
3025	Connecting rod cap bolt	489B	05	Tubdodhot
3026	Connecting rod cap bolt nut	490	03	Tubdquable
3027	Connecting rod cap bolt cotter pin	500	01	Tubducemus
3029	Connecting rod clamp screw (1" long)	578	05	Tubductur
3030	Crank shaft	498B	12 00	Tubdudery
3031	Crank shaft rear bearing cap	405B	1 10	Tubdunlot
3032	Crank shaft front bearing cap	406B	1 00	Tubdvort
3033	Crank shaft center bearing cap	407B	1 00	Tubdupcat
3034	Crank shaft bearing bolt (center and front) 6-1/16" long	408	15	Tubduplas
3035	Crank shaft bearing bolt nut	409	05	Tubdorrum
3036	Crank shaft rear bearing bolt (4-7/16" long)	478	15	Tubduros
3037	Crank shaft center bearing brass liner	501B	05	Tubdecorn
3038	Crank shaft center bearing brass liner	502B	05	Tubdedurl



Motor (Thermo-Syphon)—Continued

Order by these Nos.	Description	Factory No.	Price.	Code Word.
3039	Crank shaft rear bearing brass liner (Brass liners furnished .002, .004 or .006 thick as required)	503B	05	Tubdenock
3040	Crank shaft starting pin (2-11/16" long)	529B	05	Tubdepeir
3041	Cam shaft	410	6 00	Tuberamid
3042	Cam shaft front bearing	411	50	Tuberanol
3043	Cam shaft center bearing	412B	40	Tubervrox
3044	Cam shaft rear bearing (bronze)	413	30	Tubexeuse
3045	Cam shaft bearing ring	534	05	Tubexplic
3046	Cam shaft bearing set screw	414	05	Tubfeudo
3047	Cam shaft gear—large	415	1 50	Tubfeum
3048	Cam shaft gear—small	416	1 00	Tubfeunos
3049	Cam shaft gear dowel pin	417	05	Tubfidros
3050	Cam shaft large gear lock nut	475	15	Tubfolice
3051	Cam shaft small gear key	477	05	Tubfolion
3052	Exhaust and inlet valve	424B	30	Tubfolius
3053	Exhaust and inlet valve bushing	428	15	Tubfolom
3053 1/2	Valve Bushing for Cylinder with enclosed valves	428B	15	
3054	Intake valve spring	430	10	Tubfumes
3055	Exhaust valve spring	431	10	Tubfuscus
3056	Valve spring seat	425	05	Tubfusk
3057	Valve spring seat pin	429	01	Tubgemine
3058	Push rod	426	30	Tubgeher
3059	Push rod bushing (brass)	427	20	Tubgenus
3059 1/2	Push rod bushing (iron)	427B	15	
3060	Exhaust pipe	511	1 50	Tubgibeux
3061	Exhaust pipe pack nut—brass	512	40	Tubglabre
3062	Inlet pipe	512	2 00	Tubglacal
3063	Inlet and exhaust pipe gasket	513	05	Tubgronde
3064	Inlet and exhaust pipe gland	514	05	Tubhasitah
3065	Inlet and exhaust pipe clamp	515	15	Tubhaste
3066	Inlet and exhaust pipe clamp stud (3-5/16" long)	516	05	Tubhircos
3067	Inlet and exhaust pipe clamp nut	517	03	Tubhircum
3068	Breather pipe (brass 1 1/4" long)	522	20	Tubicurry
3069	Crank and trans. case assembly	1526B	20 00	Tubidreso
3069 1/2	Crank case front and bearing		1 50	
3070	Crank case and cyl. gasket—left	986	10	Tubiendo
3071	Crank case and cyl. gasket—right	887	10	Tubieron
3072	Crank case and cyl. cover cap screw	433	05	Tubrfott
3073	Crank case arm bolt—side (2 1/4" long)	479	05	Tubigites
3074	Crank case arm bolt—top (25/32" long)	480	05	Tubilla
3075	Crank case arm bolt nut	481	03	Tubilmer
3076	Crank case front end frame bearing	320B	60	Tubilnasty
3077	Crank case front end bearing cap.	321	40	Tubilnees
3078	Crank case front end bearing screw	322	05	Tubilnima
3079	Crank case overflow pet cock	1515	25	Tubimock
3080	Trans. drain cup—plug	817	05	Tubimos
3081	Crank case oil tube	543B	50	Tubimudy
3082	Crank case oil tube clamp (on magneto coil support)	548B	10	Tubimughto
3083	Trans. case arm block—wood	890	05	Tubinana
3084	Engine pan—right	1330	60	Tubinanis
3085	Engine pan—left	1331	60	Tubinda
3086	Trans. pan—left	1332	30	Tubindate
3087	Trans. pan—right	1333	30	Tubindebat
3088	Engine and trans. pan bolt	1335	05	Tubindece
3089	Engine and trans. pan nut	1336	02	Tubundesoo




Plate 8—Motor Parts






Plate 9—Commutator Parts

Motor (Thermo-Syphon)—Continued

Order Nos. by these	Description	No. Factory	Price.	Code Word.
3100	Crank case with lower cover	800D	20 00	
3101	Crank case lower cover	1582	1 00	
3102	Crank case lower cover gasket	1586	10	
3103	Crank case lower cover screw	1584	03	
3110	Cylinder valve cover	656	40	
3111	Cylinder valve cover gasket	660	06	
3112	Cylinder valve cover stud	654	10	
3113	Cylinder valve cover thumb nut	655	05	

Motor—Pump Circulation

(Used on Cars 1 to 2600).

400	Cylinder with head assembled	28 00	Tubdelega
400A	Cyl. only (7/16" holes for cap screws)	24 00	Tuonelock
401	Cyl. head (3/4" holes for cap screws)	4 00	Tubdelury
401B	Cyl. head (7/16" holes for cap screws)	4 00	Tubdement
402	Cyl. head gasket	75	Tubdented
403	Cyl. cover (front end)	1 25	Tubdepost
483	Cyl. head cap screw (3/8")	05	Tubdigens
483B	Cyl. head cap screw (7/16")	35	Tubdepostur
446	Cyl. head outlet brass connection (3/4")	60	Tubdiacox
446B	Outlet brass connection (7/16" bolt)	60	Tubdibbel
550	Outlet brass conn. screw (3/8")	05	Tubdigite
550B	Outlet conn. screw (1/16")	05	Tubdihot
445	Outlet brass conn. gasket	15	Tubdiata
448	Outlet hose (1 1/4" inside x 1 1/4")	40	Tubdialet
554	Outlet hose clip	10	Tubditas
505	Cyl. cover paper liner	30	Tubditid
442	Cyl. water inlet brass connection	15	Tubdituro
444	Cyl. water inlet pack nut		
568B	Piston assembly (3 ring type—used with connecting rod having piston pin bushing)	2 50	Tubdivine
418	Piston only	2 00	Tubdivisti
419	Piston pin	35	Tubdoceas
420	Piston pin screw	05	Tubdoceba
667	Connecting rod assembly (bushing in head end)	3 00	Tubdolor
423	Connecting rod piston pin bushing	25	Tubducton
496	Crank shaft	12 00	Tubdument
530	Crank shaft ratchet	40	Tubepinex
529	Crank shaft ratchet pin	03	Tubequal
543	Crank case oil tube	50	Tubepost
520	Crank case front end frame bearing	60	Tublilnem
581	Breather pipe (1" tube)	90	Tubnorido
800	Crank case and trans. lower case.	20 00	Tubdiidres

Commutator

3800	Commutator	404	2 75	Tubindud
3801	Commutator body	457C	1 00	Tubinental
3201B	Commutator body		1 00	
3203	Commutator cover	461B	15	Tubinfer
3202 1/4	Commutator cover thumb nut	634	05	Tubinferol
3203	Commutator cover screw (R. H. 3/4" long)	495	02	Tubinfos
3203B	Commutator cover screw (L. H. 3/4" long)		02	
3204	Commutator body screw	463	02	Tubunfoud






Plate 10—Fly Wheel, Magneto and Fan Parts




Plate 10-A Magneto Parts



Commutator—Continued

Order by these Nos.	Description	Factory No.	Price.	Code Word.
3205	Commutator brush (State size of roller) .....	574	75	Tubinfule
3206	Commutator brush cap (steel) ..	468	05	Tubunsulo
3207	Commutator brush cap pin ..	466	02	Tubintrat
3208A	Commutator fibre (5/8" thick x 2 3/4" O. D.) .....	575A	1 00	
3208B	Commutator fibre (3/4" thick x 2-11/16" O. D.) .....	575B	1 00	
3208C	Commutator fibre (11/16" thick x 2-13/16" O. D.) .....	575C	1 00	
3209	Commutator contact point .....	464	10	Tubinvine
3210	Commutator contact point nut ..	472	05	Tubinvito
3211	Commutator contact point fibre insulator .....	473	05	Tubirate
3212	Commutator thumb nut-brass ..	467	05	Tubiranno
3213	Commutator felt ring .....	474	10	Tubirateco
3214A	Commutator roller (5/16" x 5/8") ..	470B	10	
3214B	Commutator roller (5/16" x 3/8") ..	470A	10	
3214C	Commutator roller (15/32 x 5/8") ..	470C	10	
3214D	Commutator roller (7/16 x 11/16") ..	470D	10	
3215A	Commutator roller pin (3/16 x 3/8") .....	465A	02	
3215B	Commutator roller pin (3/16 x 5/8") .....	465B	02	
3215C	Commutator roller pin (7/32 x 21/32) .....	465C	02	
3216	Commutator roller arm (State size roller) .....	460B	30	Tubireld
3217	Commutator roller arm pin .....	476	02	Tubiremo
3218	Commutator roller spring .....	469	05	Tubiriams
3219	Commutator roller and arm .....	571	40	Tubireno
3220	Commutator lock nut .....	471	10	

Magneto

3250 1/2	Magneto coil assembly (used in connection with 9/16" magnets)	591B	12 00	Tubissoir
3250 3/4	Magneto coil assembly (used in connection with 5/8" magnets)	591C	12 00	Tubissmar
3252	Magnet coil support screw to crank case .....	486	05	Tubisse
3254	Magnet bolt (1-3/16" long) .....	537	05	Tubista
3255	Magnet washer .....	540	05	Tubistels
3256	Magnet washer screw (1 1/4" long)	541A	05	Tubitaped
3256 1/2	Magnet washer screw (2" long)	541B	05	Tubitaped
3257	Magnet brass supports (length 3/4") .....	535B	15	Tubitaro
3257 1/2	Magnet brass supports (29/32" long) .....	535C	15	Tubitaro
3258	Magnet clamp screw wire (44" long) .....	568	05	Tubitates
3259	Magnet clamp screw wire (30" long) .....	569	05	Tubitate
3260	Magneto contact assembly (on trans. cover) .....	1545	50	Tubjaemus
3261	Magneto contact thumb nut .....	1508	10	Tubjacent
3262	Magneto contact spring .....	1509	05	Tubjected
3263	Magneto contact washer (brass) ..	1510	05	Tubjection
3264	Magneto contact tube with fibre ..	1516	20	Tubjectif
3266	Magneto insulating fibre washer screw .....	1505	03	Tubjewel
3269	Fly wheel (style used on cars 1 to 17500) .....	701	7 00	Tubjubago
3269 1/2	Fly wheel (style used on cars 17500 to 20500) .....	701A	7 00	Tubjubador
3269 3/4	Fly wheel (style used on cars above 20500) .....	701B	7 00	Tubjubacon



Plate 11—Transmission Parts



## Magneto—Continued

Order by these Nos.	Description	Factory No.	Price.	Code Word.
3270	Fly wheel cap screw .....	721	10	Tubjugdor
3271	Fly wheel dowel pin .....	722	10	Tubjugete
3272	Magneto coil support shim .....	584	10	Tubjurtig
3273	Magnet bronze support (used on cars below 2500) .....	535	3 00	Tubitaron
3275	Magnet (thickness at face 9/16") .....		75	Tubissimere
3276	Magnet (thickness at face 5/8" used on cars above 20500) .....		50	Tubissimine
3277	Magnet clamp .....	623	05	Tubbissiman
3278	Magnet clamp screw .....	625	06	Tubbissimos
3279	Magneto insulating washer .....	563	04	Tubissimack

## Transmission

3300	Transmission assembly with fly wheel .....	744B	70 00	Tubjugmos
3301	Trans. reverse plate assembly .....	747	6 50	Tubjugorm
3302	Trans. reverse plate .....	703	2 50	Tubjuncto
3304	Trans. reverse gear (20 teeth) .....	703	2 75	Tubjunk
3304	Trans. reverse gear bushing .....	705	1 00	Tubjurm
3305	Trans. reverse plate rivet .....	708	02	Tublaba
3306	Trans. slow speed plate assembly .....	748	6 75	Tublabana
3307	Trans. slow speed plate .....	706	2 50	Tublabend
3308	Trans. slow speed gear (21 teeth) .....	707	3 00	Tublaba
3309	Trans. slow speed gear bushing .....	745	1 00	Tublabo
3310	Trans. slow speed plate rivet .....	708	03	Tublaba
3311	Trans. brake drum assembly .....	750	10 00	Tublalold
3312	Trans. brake drum only .....	709	5 00	Tublalone
3313	Trans. triple gear assembly .....	751B	6 00	Tublalobus
3314	Trans. triple gear bushing .....	716A	50	Tublalrat
3314½	Trans. triple gear flanged bushing .....	716B	50	Tublalriv
3315	Trans. triple gear shaft .....	715	50	Tublalacans
3316	Trans. triple gear riveting pin .....	720	05	Tublalacrim
3317	Trans. driven gear (27 teeth) .....	713	3 00	Tublalapsar
3318	Trans. driven gear key .....	714	10	
3319	Trans. driven gear sleeve (on brake drum) .....	710	4 00	Tublalapsi
3320	Trans. driven gear sleeve bushing .....	754	60	Tublalapodo
3320½	Trans. driven gear thrust washer .....	761	50	
3321	Trans. driving plate assembly (including clutch fingers) .....	749	8 00	Tublalquad
3323	Trans. driving plate screw .....	731	10	Tublalarm
3324	Trans. driving plate key .....	734	10	Tublalatart
3325	Trans. driving plate rivet .....	736	03	Tublaltine
3326	Trans. driving plate hub .....	743	3 00	Tublaltion
3327	Trans. driving plate bushing .....	724	50	Tublaltoro
3328	Trans. thrust plate (13 small) each .....	727	30	Tublaltuss
3329	Trans. thrust plate (13 large) each .....		30	Tublaltavams
3330	Trans. distance plate .....	729	40	Tublaltavets
3331	Trans. gear shaft .....	723B	4 40	Tublalteten
3332	Trans. clutch disc drum .....	725B	3 00	Tublaltectory
3333	Trans. clutch disc drum key .....	726B	10	Tublaltedder
3334	Trans. clutch disc drum set screw .....	752	05	Tublaltifty
3336	Trans. clutch push ring .....	704	2 00	Tublaltigero
3337	Trans. clutch finger .....	732B	50	Tublaltet
3337½	Trans. clutch finger screw .....	756	05	
3337¾	Trans. clutch finger washer .....	759	01	
3338	Trans. clutch finger pin .....	735	10	Tublaltvaba
3340	Trans. clutch spring .....	737	50	Tublaltvad
3341	Trans. clutch spring support .....	738	50	Tublaltvaen
3342	Trans. clutch spring thrust ring pin .....	739	10	Tublaltveto
3343	Trans. clutch spring thrust ring .....	740	1 20	Tublaltvo
3344	Trans. clutch shift .....	733	2 00	Tublalticam




Plate 12—Control Parts



**Transmission Cover**

Order by these Nos.	Description	Factory No.	Price	Code Word
3360	Trans. cover complete with pedal assembly (1910) (Square door type—used with closed crank case)	1563	18 00	Tublicory
3360½	Trans. cover complete with pedal assembly (1911) (Sloping door type—used with crank case having detachable lower plate)		18 00	
3361	Trans. cover only (1910)	826C	9 00	Tublicutt
3362	Trans. cover bolt (1-1/32")	825B	05	Tublicory
3363	Trans. cover felt	872	10	Tublicyrx
3364	Trans. cover gasket (2 pcs.)	825	15	Tubliderty
3365	Trans. cover door	1548C	75	Tublidunx
3366	Trans. cover door gasket	1547B	10	Tublicefon
3367	Trans. cover door screw	1564	05	Tubligert
3368	Universal ball cap (rear)	818	75	Tublifort
3369	Universal ball cap (front)	819B	2 50	Tublifuler
3371	Universal ball cap bolt (13/16")	822B	05	Tubligolly
3372	Universal jt. ball cap bolt (1½")	1538	05	Tublihogit
3373	Universal ball cap bolt nut	828	03	Tublihurty
3374	Trans. cover bolt (1-7/32")	1570	05	Tublis
3375	Trans. cover screw (1¼")	1567	05	Tubline
3376	Trans. cover with sloping door (1911)	826D	9 00	Tublitt
3377	Trans. cover gasket (2 pcs.)	825E	15	Tublito
3378	Trans. cover sloping door	1546D	80	Tublites
3379	Trans. cover sloping door gasket	1547C	10	Tublter
(Order parts below for Cars numbered below 2500).				
723	Trans. shaft		4 40	Tublcase
725	Trans. disc drum		3 00	Tublebe
728	Trans. disc drum key		10	Tublctar
716	Triple gear bushing		50	Tublbrat
712	Driven gear sleeve bushing (2) each		50	Tublaposis

**Transmission Control—Three Pedal Type**

3400	Trans. clutch release ring (bronze)	741	1 50	Tublmita
3401	Clutch lever	806B	30	Tublmixer
3402	Clutch lever shaft (9½" long)	833B	25	Tublmotz
3403	Clutch lever screw	1641	10	Tublnotery
3404	Clutch lever screw nut	1542	05	Tubloyal
3405	Clutch lever pin	1554	03	Tublzero
3406	Clutch release fork—right	334	50	Tublucana
3407	Clutch release fork—left	894	50	Tublaid
3408	Clutch release fork key	836	05	Tubluctus
3409	Clutch release fork clamp screw	835	05	Tubluebat
3410	Clutch release fork clamp screw wire	837	02	Tublvero
3411	Clutch and reverse lever clevis pin	857	02	Tublumis
3413	Trans. bands (3) each	838B	1 20	Tublunase
3414	Trans. band ear	839B	20	Tubluteos
3415	Trans. band washer	840	02	Tubluxias
3418	Trans. band raybestos lining	1555	50	Tublyre
3419	Trans. band adjusting screw	1533	15	Tubmacon
3420	Trans. band adjusting screw nut (¾" hole)	1532	05	Tubmagical
3421	Trans. band rivet (3/16" x 7/16") per doz.	842	05	Tubmarnas
3422	Trans. band rivet (3/16" x ½") per doz.	843	05	Tubmedial
3423	Trans. band rivet (3/32" x ½") per doz.	844	05	Tubmedios
3424	Trans. band rivet (3/32" x 7/32") per doz.	845	05	Tubmerge

**Transmission Control—Three Pedal Type**

Order by these Nos.	Description	Factory No.	Price	Code Word
3425	Trans. band spring	841B	05	Tubmergin
3428	Trans. band adjusting nut (7/16x 20 th'd)			
3427	Slow speed shaft	851	05	Tubmergus
3428	Slow speed notch	848B	30	Tubmerhuf
3429	Slow speed notch pin	829B	50	Tubmicky
3430	Slow speed shaft washer	1560	03	Tubmidway
3432	Speed lever	1559	05	
3433	Speed lever clevis pin	853B	40	Tubmiggot
3434	Reverse pedal	893	05	Tubmiss
3435	Brake and reverse pedal shafts (2) each	853B	1 25	Tubmitoy
3438	Brake and reverse pedal support (2) each	849B	20	Tubmixa
3437	Brake and reverse support bolts (2) each	1530	30	Tubmiyave
3438	Brake and reverse support bolt nuts (2) each	1534	10	Tubmotixn
3439	Brake pedal	1535	05	Tubmovhen
3440	High and slow speed pedal (1910)	852B	1 25	Tubmuddy
3441	Pedal pins (3) each	854B	1 25	Tubmufatt
3442	High and slow speed pedal support	1553	05	Tubmugerxn
3443	High and slow speed pedal support bolt	1531	30	Tubmumavy
3444	High and slow speed pedal support bolt nut	1536	05	Tubmuney
3445	Slow speed connection	1540	05	Tubmvellit
3448	Slow speed connection lock nut	850	15	Tubmurton
3447	Slow speed connection clevis	802	02	Tubmyrgus
3448	Controller quadrant	309B	25	Tuboload
3449	Controller shaft with speed lever assembled		60	Tuberaxi
3450	Controller shaft bracket	867C	1 00	Tuhozalt
3451	Controller shaft bracket felt	311	25	Tubmurmer
3452	Controller shaft bracket bolt	314	10	Tubmused
3453	Controller shaft bracket nut	315	05	Tubmutedo
3455	Hand brake lever assembly (1910)	316	03	Tubmutque
3456	Hand brake lever pin	1550	2 50	Tubnascel
3457	Hand brake lever key	866	02	Tubnatabo
3458	Hand brake lever pawl	874	05	Tubnatds
3459	Hand brake lever pawl pin	875	20	Tubnaviga
3460	Hand brake lever pawl rod (1910)	876	05	Tubnavimo
3462	Hand brake lever pawl lift (includes spring)	877	15	Tubnectes
3463	Hand brake lever pawl lift spring	879	40	Tubnectum
3465	Hub brake lever on controller shaft	888	05	
3466	Hub brake lever pin	864	40	Tubnegart
3467	Hub brake lever clevis	865	02	Tubnerons
3468	Hub brake pull rod—right	47	25	Tubnerra
3469	Hub brake pull rod—left	891B	45	Tubnervas
3470	Hub brake pull rod support—right	1513B	45	Tubnervo
3471	Hub brake pull rod support—left	1367C	15	Tubnerzor
3472	Hub brake pull rod support belt (1" long)	1398C	15	Tubnethin
3473	Hub brake pull rod support bolt nut	1399B	05	Tubnexas
3474	Hand brake lever assembly (runabout)	1900	02	Tubneyzal
3475	Hand brake lever pawl rod (Runabout)	1590	2 50	
3476	High and slow speed pedal (runabout)	1593	15	
3477	Brake pedal (Runabout)	1591	1 25	
		1592	1 25	



Steering Gear

Order by these Nos.	Description	Factory No.	Price.	Code Word.
3500	Steering gear assembly 1909-10 type (50" long)	900	20 00	Tubneuter
3501	Steering gear rim (13" O. D.)	901	1 80	Tubneutro
3502	Steering gear rim screw	819	05	Tubnixed
3503	Steering gear spider	902	1 60	Tuborno
3504	Steering gear cover	903	1 00	Tubostend
3505	Steering gear cover screw	910	05	Tuboval
3506	Steering gear cover bushing	914	25	Tubovtrae
3507	Steering gear internal gear case	904	1 50	Tuboxice
3508	Steering gear case bushing	905	1 25	Tuopectin
3509	Steering gear quadrant	908	1 20	Tubpenne
3510	Steering gear quadrant pin	907	05	Tubperfor
3511	Steering gear wheel nut	913	30	Tubjetroi
3512	Steering gear tubing assembly (Includes gear case, also lead and throttle rods) (27" long)	949	8 00	Tubpliquant
3513	Steering gear tubing flange screw	927	10	Tubplinth
3514	Steering gear tubing flange screw nut	926	10	Tubplinós
3515	Steering gear tubing flange screw washer	925	05	Tublisse
3516	Steering gear post (51" long)	915	2 50	Tubpolar
3517	Steering gear pinions (3) each	916	50	Tubporan
3518	Steering gear pinion pin (3/8" x 1-1/16")	917	06	Tubprefer
3519	Steering gear drive pinion	911	1 00	Tubprior
3520	Steering gear driving pinion key	909	05	Tubpuarto
3521	Steering gear pinion shaft bushing	912	30	Tubradend
3523	Steering gear post castle nut	951	05	Tubradie
3524	Throttle rod	933	50	Tubrados
3525	Lead rod	934	50	Tubraleam
3526	Lead and throttle handle (rubber)	918	25	Tubrameal
3527	Lead throttle rod spring	935	10	Tubramoso
3528	Lead & throttle rod collar	936	10	Tubrasas
3529	Lead & throttle rod collar pin	927	05	Tubrasuro
3530	Lead rod lever	948	30	Tubraucld
3531	Throttle rod lever	947	30	Tubraucos
3532	Throttle rod guide	938	40	Tubraudad
3533	Throttle rod and lead lever pin	948	02	Tubray
3534	Commutator pull rod (14" long)	1325B	25	Tubrayater
3535	Carburetor pull rod (13-13/16" long)	1329	30	Tubrayn
3536	Lead lever ball and socket joint	1326	30	Tubrayo
3537	Lead lever ball and socket joint nut	1327	03	Tubrayors
3538	Carburetor pull rod adjustment	1904	15	Tubregang
3539	Steering post bracket with bushing	932	2 50	Tubregano
3540	Steering post bracket bolt (2 3/4" long)	939	20	Tubregon
3541	Steering post bracket bolt (3/4" long)	940	10	Tubridebe
3542	Steering post bracket bolt nut	941	05	Tubrident
3544	Steering post bracket felt washer	943	10	Tubrigor
3545	Steering post bracket bushing (bronze)	944	1 00	Tubrigous
3546	Steering post bracket block	945	10	Tubrigum
3547	Steering gear ball arm	929B	1 20	Tubrihort
3548	Steering gear ball arm key	930	10	Tubrusion

Steering Gear—1911 Touring Car

3550	Steering gear assembly (56" long)	900B	30 00
3551	Steering gear rim (15" O. D.)	901B	1 60
3552	Steering gear spider	902B	1 60




Plate 13—Steering Gear Parts






Plate 14—Floor Board and Dash with Parts

Steering Gear—Continued

Order of these Nos.	Description	No.	Price.	Code Word.
3553	Steering gear post (53" long) ..	915B	2 50	
3554	Steering gear tubing assembly ..	949B	8 00	
3555	Steering gear tubing flange screw (19/16") ..	954	10	
3556	Steering gear tubing flange screw (15/16") ..	956	10	
3559	Steering gear case bushing .....	905B	1 25	
3560	Throttle lever rod .....	933B	50	
3561	Lead lever rod .....	934B	50	
3562	Steering post bracket with bushing .....	932B	2 50	
3563	Steering post bracket grease cup (For other parts of this assembly see Nos. 3500 to 3548)	955	25	

Steering Gear—1911 Runabout

3575	Steering gear assembly (61" long) .....	979	20 00	
3576	Steering gear tubing assembly (34" long) .....	963	8 00	
3577	Steering gear post (59" long) ..	959	2 50	
3578	Throttle lever rod .....	957	50	
3579	Lead lever rod .....	958	50	
3580	Steering post bracket with bushing .....	953	1 50	
(Parts 3551-3552-3555-3556-3563-apply to this assembly: —Other parts listed under Nos. 3500 to 3548.)				

Body Parts—1909-10 Touring Car

3601	Body bracket on body (front end)	1002	10	Tubogaor
3601 1/2	Body bracket on body (centre and rear) .....		10	Tubrob
3602	Body bracket connecting bolt (1 1/2" long) .....	1304	05	Tubroanuss
3603	Body bracket connecting bolt (25/32" long) .....	1305	05	Tubroanuss
3605	Body bracket connecting bolt nut (square) .....	1307	05	Tubroine
3606	Body bracket bolt nut (hexagon)	1001	03	Tubrole
3607	Tonneau carpet for touring car ..	1606	2 50	Tubronde
3607 1/2	Tonneau carpet for Town car ..		2 50	Tubronde
3607 1/2	Carpet for coupe .....		2 50	Tubronde
3609	Tonneau door strap .....	1605	35	Tubroste
3611	Tonneau door handle .....	1443	60	Tubrufarm
3612	Tonneau door handle screw .....	1479	05	Tubrumax
3613	Tonneau door lock—left .....	1442B	1 50	Tubrumshot
3614	Tonneau door lock—right .....	1444B	1 50	Tubrunuit
3615	Tonneau door lock striker plate (left) .....	1445B	30	Tubrunita
3616	Tonneau door lock striker plate (right) .....	1446B	30	Tubrupter
3617	Tonneau door hinge assembly—right .....	1632	1 00	Tubrustic
3618	Tonneau door hinge assembly—left .....	1633	1 00	Tubruttle
3619	Tonneau door hinge pin .....	1012	10	Tubruito
3620	Tonneau heel board hinge .....	1019	15	Tubrsaline
3621	Tonneau heel board latch .....	1020	35	Tubrsalsam
3624	Front floor rubber matting .....	1616	3 00	Tubrsalt
3626	Floor board (first) .....	1096B	35	Hubsanact
3627	Floor board (second) .....	1402B	40	Tubsanerz
3628	Floor board (third) .....	1404B	30	Tubsanorx



Body Parts—1909-10 Touring Car—Continued

Order by these Nos.	Description	No. Factory	Price.	Code Word.
3629	Floor board (fourth)	1403B	35	Tubsatrat
3630	Floor board forward plate for pedals	1400B	50	Tubsayert
3632	Floor board rear plate for pedals	1095B	40	Tubsautid
3633	Floor board plate for side lever	1094B	35	Tubsautid
3634	Dash	1091B	6 00	Tubsdaylen
3635	Dash brass moulding	1063	1 50	Tubsecutyn
3638	Dash shield	1097B	20	Tubseqvox
3640	Dash bracket (left)	1017	50	Tubserite
3641	Dash bracket (right)	1018	50	Tubserved
3642	Dash bracket bolt (on frame)	1028	05	Tubservin
3643	Dash bracket bolt nut	1039	05	Tubsessa
3645	Dash bracket top bolt	1039	05	Tubsessle
3646	Dash bracket lower bolt	1032	05	Tubsessix
3649	Dash bracket top bolt nut	1035	03	Tubsessue
3650	Dash bracket lower bolt nut	1036	03	Tubsiccas
3651	Dash to body bracket	1489	15	Tubsidor
3652	Dash to body bracket bolt (on body)	1490	05	Tubsidunt
3653	Dash to body bracket bolt (on dash)	1491	05	Tubsifan
3654	Dash to body bracket bolt nut	1492	03	Tubsifer
3655	Oil lamp bracket—right (touring car)	1497	40	Tubsiform
3656	Oil lamp bracket—left (touring car)	1498	40	Tubsign
3657	Oil lamp bracket brass screw	1503	05	Tubsignal
3658	Oil lamp bracket screw nut	1608	05	Tubsigned
3659	Oil lamp bracket screw washer	1627	03	Tubsimile
3660	Tail lamp bracket (touring car)	1613	25	Tubsimone
3661	Tail lamp bracket bolt	1614	05	Tubsimor
3662	Tail lamp bracket bolt nut	1615	05	Tubspimo
3663	Gas lamp bracket—right	1301	1 00	Tubspic
3664	Gas lamp bracket—left	1348	1 00	Tubspunt
3665	Gas lamp bracket nut	1302	05	Tubspist
3667	Front seat cushion for touring car	1626	12 00	Tubspitia
3670	Rear seat cushion for touring car	1627	12 00	Tubspistor
3667 1/4	Tourabout front seat cushion—right		8 00	
3667 1/4	Tourabout front seat cushion—left		8 00	
3670 1/4	Tourabout rear seat cushion—right		8 00	
3670 1/4	Tourabout rear seat cushion—left		8 00	
3671	Oil lamp bracket—right (town car)		1 00	Tubspisten
3672	Oil lamp bracket—left (town car)		1 00	Tubspido
3673	Oil lamp bracket—right (coupe)	2200	1 00	Tubspisel
3674	Oil lamp bracket—left (coupe)	2201	1 00	Tubspismen
3675	Tail lamp bracket (coupe)		50	Tubspisog
3678	Cocoa mat (81 x 32)		3 00	

Body Parts—1911 Runabout

3700	Dash	2558	\$ 6 00
3701	Dash bracket—Right	2563	50
3702	Dash bracket—Left	2562	50
3703	Dash brass moulding	2575	1 50
3704	Oil lamp bracket—Right	2577	30
3705	Oil lamp bracket—Left	2578	30
3706	Floor board (First)	2610	30
3707	Floor board (Second)	2611	30




Plate 15—Springs and Parts






Plate 16—Parts for Pump Circulation Motor

Body Parts—Continued

Order by these Nos.	Description	No. Factory	Price.	Code Word.
3708	Floor board (Third)	2612	40	
3709	Floor board (Fourth)	2613	25	
3710	Floor board (Fifth)	2629	25	
3711	Rubber matting		3 00	
3713	Torpedo door-lock—Right		1 25	
3714	Torpedo door-lock—Left		1 25	
3715	Seat with cushion (Open Run-about)		40 00	
3716	Seat with cushion (Torpedo)		40 00	
3717	Seat cushion (one piece)		10 00	

Body Parts—1911 Touring Car

3750	Dash	1091E	6 00
3751	Dash bracket—Left	1017E	50
3752	Dash bracket—Right	1018E	50
3753	Dash bracket moulding	1063E	1 50
3754	Cocoa torneau mat (31x28)	1606E	3 00
3755	Door hinge (upper right)	2542	30
3756	Door hinge (lower left)	2543	30
3757	Door hinge (lower right)	2544	30
3758	Door hinge (upper left)	2541	30
3765	Rear body bracket	2435	40
3766	Front cushion (state size)	1626E	12 00
3767	Rear cushion (state size)	1627E	12 00

“Farm” Roadster Parts

3775	Front seat with cushions (see No. 3715)		
3776	Rumble seat with cushions		\$ 12 00
3777	Rumble seat cushion		4 00
	Rear fenders, Metal shields, Floor boards and Rubber matting same as 1911 Touring Car. Front fenders, Running Boards, Steering gear and Dash same as 1911 Touring car.		

Springs

3800	Front spring (specify color)	332	6 00	Tubsturn
3801	First leaf (main leaf)	354	1 25	Tubsold
3802	Second leaf	385	1 10	Tubsoil
3803	Third leaf	356	1 00	Tubsolled
3804	Fourth leaf	357	90	Tubsolad
3805	Fifth leaf	358	75	Tubsolano
3806	Sixth leaf	359	60	Tubsolary
3807	Seventh leaf	360	40	Tubsolus
3808	Front spring clip	325E	25	Tubsolve
3809	Front spring clip nut	327	05	Tubsolvin
3811	Front spring tie bolt	1362	05	Tubsonaba
3812	Front spring tie bolt nut	1363	02	Tubsortit
3813	Front spring hanger (wide flange)	246	50	Tubsparg
3814	Front spring hanger (narrow flange)	229	50	Tubstrunt
3815	Front and rear spring hanger nut	220	02	Tubsume
3817	Front and rear spring hanger roller	267	15	Tubtender
3818	Front spring perch—right	222	1 00	Tubtenses
3819	Front spring perch—left	223 1/2	1 00	Tubtersago
3820	Front spring perch bushing	230	20	Tubtereba
3821	Front spring perch nut	242	05	Tubterfue
3823	Front spring leather	262	10	Tubtevac



**Springs—Continued**

Order by these Nos.	Description	No.	Price.	Code Word.
3824	Rear spring	333	14 00	Tubterit
3825	First leaf (main leaf)	361	2 60	Tubterra
3826	Second leaf	362	2 25	Tubtlando
3827	Third leaf	363	2 00	Tubtlatel
3828	Fourth leaf	364	1 75	Tubtlla
3829	Fifth leaf	365	1 60	Tubtlliba
3830	Sixth leaf	366	1 50	Tubtllise
3831	Seventh leaf	367	1 30	Tubtllity
3832	Eighth leaf	368	1 10	Tubtlliear
3833	Rear spring clip	326	25	Tubtinies
3834	Rear spring clip nut	328	05	Tubttuba
3835	Rear spring clip bar	329	10	Tubtlve
3837	Rear spring tie bolt	1352	03	Tubtly
3838	Rear spring tie bolt nut	1353	02	Tubtonic
3840	Rear spring hanger (narrow flange)	91	50	Tubtorse
3841	Rear spring hanger (wide flange)	91½	50	Tubtraca
3842	Rear spring leather pad	94	15	Tubtrack
3843	Rear spring perch	41	60	Tubtracto
3844	Rear spring perch bushing	172	20	Tubtraho
3845	Rear spring perch nut	174	05	Tubtrahr
3846	Rear spring clip (Runabout)	399	25	
3847	Front spring retainer clip with rivet		10	
3848	Rear spring retainer clip with rivet		10	

**Rear Spring 60" Tread**

3850	Rear spring	1704	14 00
3851	Rear spring clip	1737	25
3852	Rear spring tie bolt	1738	10
3853	First leaf (main leaf)	1739	2 60
3854	Second leaf	1740	3 25
3855	Third leaf	1741	2 00
3856	Fourth leaf	1742	1 75
3857	Fifth leaf	1743	1 60
3858	Sixth leaf	1744	1 50
3859	Seventh leaf	1745	1 30
3860	Eighth leaf	1746	1 10

**Pump**

551	Pump assembly	9 00	Tubtridd
434	Pump body	4 00	Tubtrilo
435	Pump Cover	2 00	Tubtrilem
443	Pump cover gasket	10	Tubtriste
452	Pump cover screw	05	Tubtripos
436	Pump fan	1 00	Tubtrude
437	Pump shaft	1 00	Tubturbin
454	Pump fan pin	01	Tubtuto
451	Pump packing nut (right hand)	25	Tubturtorm
451½	Pump packing nut (left thread)	25	Tubuculam
450	Pump thrust washer (steel)	10	Tubuculo
576	Pump drive gear and shaft	2 50	Tubucularia
438	Pump drive gear only	1 50	Tubule
439	Pump drive gear shaft only	1 00	Tubulines
440	Pump drive gear shaft bushing (rear)	25	Tubullpap
453	Pump drive gear shaft bushing (front)	25	Tubullped
577	Pump inlet connection assembly	1 00	Tubumdon
558	Pump inlet connection pet cock	30	Tubunctis
465	Pump inlet nut	30	Tubungor
507	Pump inlet hose 1¼" inside x 3¼"	30	Tubungual

**Pump—Continued**

Order by these Nos.	Description	Factory No.	Price.	Code Word.
555	Pump inlet hose clip		10	Tubunguit
456	Pump support screw		05	Tuburb
496	Radiator fan and shaft		2 00	Tuburbain
496½	Radiator fan only		1 00	Tuburpago
497	Radiator fan rivet		03	Tuburbana

**Starting Crank**

3906	Starting crank only	515B	1 00	Tuburbigut
3901	Starting crank handle (rubber)	520	40	Tuburblo
3902	Starting crank handle bolt	521	20	Tuburend
3903	Starting crank sleeve (steel tubing)	523B	30	Tubutten
3905	Starting crank ratchet pin (1¼" long)	527B	05	Tubvonder
3906	Starting crank ratchet	528B	35	Tubvutlgo
3907	Starting crank strap	1963	30	Tubvuzelt
3908	Starting crank spring (brass)		05	Tubvolt
519	Starting crank only		1 00	Tuburbial
522	Starting crank handle bolt nut		05	Tuburimus
523	Starting crank sleeve		50	Tuburran
524	Starting crank collar pin		02	Tubvadem
525	Starting crank collar		25	Tubvectab
526	Starting crank spring		10	Tubvelout
527	Starting crank ratchet pin		02	Tubven
528	Starting crank ratchet		35	Tubvencas

**Radiator (Thermo-Syphon)**

3925	Radiator-thermo-Syphon	1100C	28 00	Tubvectil
3926	Radiator cap	1103B	50	Tubvedon
3927	Radiator cap gasket (fibre)	1117	05	Tubvenga
3928	Radiator pad (leather)	1105	05	Tubvendia
3929	Radiator stud	1164	05	Tubveno
3930	Radiator stud spring	1154	05	Tubvenol
3931	Radiator stud nut	1154	05	Tubvence
3931½	Radiator stud washer	1161	05	Tubveld
3932	Radiator rod (20¼" long)	1111B	25	Tubvenscot
3933	Radiator rod washer	1112	05	Tubversod
3934	Radiator rod nut	1113	05	Tubverse
3939	Outlet connection pipe (see motor plate)	1121	50	Tubveruly
3940	Outlet connection cock	594	25	Tubvester
3944	Outlet connection hose (1¼" inside x 2¼")	507B	30	Tubvexis
3945	Outlet connection hose clip	564	10	Tubveyix
3946	Radiator stay rod (22¼" long)	1167	25	

**Radiator (Pump Circulation)**

1100	Radiator (pump circulation)		28 00	Tubvendra
1111B	Radiator stay rod (state length)		25	Tubverif

**Radiator Fan (Thermo-Syphon Motor)**

3960	Fan & pulley assembly	619	2 00	Tubiah
3961	Fan blades, each	611	25	Tubvtabot
3962	Driven fan pulley (brass)	619	1 00	Tubviacod
3963	Fan drive pulley	602	30	Tubviacogi
3964	Fan belt	609	60	Tubviacux
3965	Fan tension spring	610	05	Tubviadox
3966	Fan shaft	606	25	Tubviadunt
3967	Fan bracket	604	40	Tubviafule
3968	Fan bracket bolt	605	15	Tubviaflyt
3970	Fan oiler assembly	601	20	Tubviaagin
3971	Fan oiler body	598	10	Tubviagore
3972	Fan oiler cap	616	10	Tubviahay
3973	Fan adjusting screw	645	10	
3974	Fan adjusting screw lock nut	646	05	






Plate 17—Radiator and Parts

Order by these Nos.	Description	Factory No.	Price.	Code Word.
4025	Muffler assembly	1200B	2 50	Tubvesper
4026	Muffler head-intake	1200B	60	Tubvtenes
4027	Muffler shell (outer)	1203	30	Tubvlinier
4028	Muffler shell (middle)	1204	25	Tubvtnmes
4029	Muffler shell (inner)	1205	60	Tubvoade
4030	Muffler rod only	1206	10	Tubvocalt
4031	Muffler rod nut	1207	05	Tubvolaba
4032	Muffler bracket—exhaust	1217	30	Tubvolem
4033	Muffler bracket—intake	1218	30	Tubway
4034	Muffler bracket bolt	1210	05	Tubworker
4035	Muffler bracket bolt nut	1211	03	Tubyaga
4037	Long exhaust pipe	1214	1 50	Tubygare
4038	Muffler asbestos	1215	15	Tubyooti
4039	Muffler asbestos bands (tin)	1216	10	Tubyhauz
4040	Rear muffler head with outlet pipe	1221	75	Tubvienta

**Hood—Touring Car**

4050	Hood—22" long (specify color)	1300	6 50	Tubyugot
4051	Hood handle	1314	25	Tubyugur
4052	Hood clip	1310	10	Tubzuar
4053	Hood clip spring	1311	05	Tubzuril
4054	Hood clip washer	1312	02	Tubcaro
4056	Hood-board—left (22 3/4" long)	1339	40	Tubceantab
4057	Hood-board—right (22 3/4" long)	1340	40	Tuccendan
4058	Hood-board bolt	1308	05	Tuccedase
4059	Hood-board bolt nut	1309	02	Tuccedbt
4060	Hood support on dash	1334	1 00	Tuccedemo
4061	Hood support screw	1350	01	Tucceden
4082	Hood clasp (on radiator)	1109B	05	

**Hood—Runabout**

4070	Hood—24" long (Specify color)	2313	6 50	Tuccedil
4071	Hood block—right (24 3/4" long)	2305	40	Tuccedot
4072	Hood block—left (24 3/4" long)	2306	40	Tuccedar

**Carburetor (1910 Kingston)**

4100	Carburetor complete		9 00	
4101	Float		80	
4102	Float chamber		2 00	
4103	Gasoline valve		50	
4104	Gasoline valve operating lever		30	
4105	Gasoline valve operating lever shaft		10	
4106	Gasoline valve cap		30	
4107	Mixing chamber		2 00	
4108	Spray nozzle		30	
4109	Center chamber		1 00	
4110	Gasket for center member		20	
4111	Gasoline needle valve		50	
4112	Gasoline needle valve set screw		05	
4114	Throttle gate screw		05	
4115	Throttle gate lever		30	
4116	Throttle gate adjusting screw		05	
4117	Throttle gate set screw		05	
4118	Gasoline intake packing nut		15	
4119	Gasoline intake elbow		25	
4120	Primer assembly		40	
4121	Primer lever only		30	
4122	Bronze ball (for air regulation)		10	
4123	Retainer cap for balls		40	
4124	Constant air supply connection		1 00	
4125	Constant air supply connection lock nut		20	
4126	Carburetor adjusting rod head		15	
4127A	Carburetor adjusting rod bracket		30	






Plate 18—Hood, Muffler and Parts




Plate 19—Kingston Carburetor and Parts





Plate 20—Holly Carburetor and Parts

Order by these Nos.	Description	Price.	Code Word.
4127B	Carburetor adjusting rod bracket for roadster .....	30	
4128	Carburetor adjusting rod head pin .....	05	
4129A	Carburetor adjusting rod (18-13/16" long) .....	25	
4129B	Carburetor adjusting rod (18-23/32" long) .....	25	
4129C	Carburetor adjusting rod (19 1/2" long) .....	25	
4131	Carburetor adjusting bracket screw .....	05	
4132	Carburetor flange bolt .....	05	
4133	Carburetor flange bolt nut .....	03	
4134	Carburetor flange gasket .....	10	
4135	Carburetor priming rod .....	20	

Carburetor (1910 Holly)

4150	Carburetor complete .....	9 00
4151	Float with lever .....	60
4152	Float chamber .....	2 00
4153	Float chamber gasket .....	10
4154	Gasoline valve .....	60
4155	Gasoline valve guide .....	50
4157	Mixing chamber .....	2 00
4158	Mixing chamber nut .....	40
4159	Gasoline needle valve .....	50
4160	Gasoline needle valve set screw .....	15
4162	Throttle lever .....	25
4163	Throttle gate lever adjusting screw .....	05
4164	Throttle gate lever set screw .....	05
4165	Screen holder and screen .....	40
4166	Gasoline intake screen .....	10
4167	Gasoline intake screen gasket .....	15
4168	Primer assembly .....	60
4170	Constant air supply .....	1 00
4171	Constant air inlet cup screw .....	10
4172	Carburetor drain cock .....	15

Carburetor—(1911 Holly)

4500	Carburetor complete .....	\$ 9 00
4502	Mixing chamber top .....	2 00
4503	Float chamber .....	2 00
4508	Float .....	60
4505	Float lever .....	25
4506	Float lever pin .....	10
4509	Spray needle .....	35
4510	Spray nozzle .....	10
4513	Mixing chamber nut .....	25
4515	Auxiliary air valve .....	15
4516	Auxiliary air valve cap .....	10
4518	Throttle lever .....	40
4522	Inlet needle pack nut .....	05
4523	Inlet needle .....	25
4524	Inlet needle guide cap .....	32
4529	Pet cock .....	15
4530	Air inlet elbow .....	85
4532	Air inlet elbow nut .....	05
4534	Primer assembly .....	60
4535	Center member .....	30



**Coil (Kingston)**

Order by these Nos.	Description	Price.	Code Word.
4200	Coil complete	30 00	Tuccinger
4201	Adjusting screw with platinum point	75	Tuecingos
4202	Vibrator spring with platinum point	60	Tuccinico
4203	Vibrator hammer	10	Tuccinide
4204	Adjusting screw lock spring	10	Tucciniel
4205	Adjusting screw bracket	40	Tuccinily
4209	Coil box complete	5 00	Tuccinon
4210	Coil box cover	80	Tuccinore
4211	Coil box cover fastener—lower	15	Tuccivus
4211½	Coil box cover fastener—upper	15	Tuccivus
4212	Coil bracket	50	Tuccivut
4214	Coil bracket stud nut	05	Tuclades
4215	Coil units, each	6 00	Tuclamea
4216	Coil unit fastener and vibrator bar	25	Tuclamo
4217	Coil unit fastener thumb nuts, each	05	Tuclavio
4218	Vibrator unit cover (fibre)	15	Tuclollad
4219	Switch plug	25	Tuclullo
4220	Switch lever	25	Tuclomba
4221	Switch cover	25	Tuclombe
4222	Switch base assembly	75	Tuclomed
4223	Hexagon nuts on bottom of coil, each	05	Tuclosta
4224	Springs for terminal connection, each	10	Tuclosita
4225	Terminal binding posts with spring	20	Tuclosorm
4226	Terminal binding post porcelain	15	Tuclosos
4227	Terminal binding post thumb nut	05	Tuclotrin
4228	Terminal binding post hexagon nut	05	Tuclour

**Coil (Kingston) New Style**

4229	Coil box complete	6 00
4230	Coil box cover	80
4231	Coil complete	30 00
4232	Coil unit	6 00
4233	Switch key	15
4234	Vibrator spring with platinum point	60
4235	Adjusting screw with platinum point	75

**Kingston Coil (1911 type—Metal covered units)**

4660	Coil assembly	30 00
4661	Coil unit (metal cover)	6 00
4663	Vibrator bridge with plat. point	75
4665	Unit knurled adjusting screw	25
4666	Vibrator with plat. point	90
4671	Unit metal cover	80
4675	Coil box cover	80
4676	Coil box with cover	6 00
4697	Switch key	15
4699	Switch lever assembly	35
4702	Switch base cover	25
4705	Switch assembly	1 50

**Heinze Coil**

4800	Coil	30 00
4802	Coil box cover	80
4604	Coil box with cover	6 00
4811	Coil unit (male)	6 00
4812	Coil unit (female)	6 00



Plate 21--Kingston Coil and Parts






Plate 22—Coil (Kingston) New Style




Plate 23—Jacobson-Brandon Coil and Parts



## Heinze Coil—Continued

Order by these Nos.	Description	Factory Nos.	Price	Code Word.
4613	Adjusting nut and ratchet		15	
4616	Vibrator with platinum point		90	
4618	Vibrator bridge with platinum point		90	
4638	Switch assembly	1	50	
4639	Switch plug		15	
4640	Switch base (includes spring)		75	
4641	Switch cover		25	
4644	Switch lever with knob		35	
4645	Switch lever knob		15	
4646	Switch lever knob set screw		02	

## Coil (Jacobson-Brandon)


4251	Adjusting screw		25	Tuccuraw
4252	Vibrator spring with platinum point	1	00	Tuccurum
4253	Cross bar with platinum point		75	Tuccurry
4254	Coil box complete	6	00	Tuccurflow
4255	Coil box cover		80	Tuccurbob
4256	Coil units each	6	00	Tuccurdo
4257	Switch complete	2	00	Tuccurgo
4258	Switch plug		25	Tuccurven
4259	Switch lever		35	Tuccurvil
4260	Switch cover		35	Tuccurbal

## Wiring

4350	Spark plug wire (15 1/4" long: No. 1 cyl.)	1365	30	Tuccurer
4351	Spark plug wire (12 1/4" long: No. 2 cyl.)	1366	30	Tuccubine
4352	Spark plug wire (8" long: No. 3 cyl.)	1375	25	Tuccubius
4353	Spark plug wire (8 3/4" long: No. 4 cyl.)	1376	20	Tuccubuer
4354	Spark plug wire terminal	1381	05	Tucculeasy
4355	Commutator wires with loom	1951	1	00 Tuccumbat
4356	Commutator wires with terminal, each		10	Tuccumal
4357	Commutator wire terminal (coil end)	1385	03	Tuccumbir
4358	Commutator wire loom only	1378	60	Tuccursen
4359	Commutator wire loom support	1390	05	Tuccursor
4360	Magneto wire to coil	1968	25	Tuccurux
4361	Commutator loom rubber nipple	1964	05	
4362	Commutator wire rubber nipple	1965	03	
4363	Commutator wire support (on dash)	1638	05	
4366	Spark plug wire (17 1/4" long: No. 1 cyl.)	2357	30	
4367	Spark plug wire (14 1/4" long: No. 2 cyl.)	2358	30	
4368	Spark plug wire (10" long: No. 3 cyl.)	2359	25	
4369	Spark plug wire (11" long: No. 4 cyl.)	2360	20	
4370	Magneto to coil wire (11 1/4" long)	2361	25	

## Special Tools

1349	Hub cap wrench		25	
1370	Disc drum puller clamping screw		10	
1387	Adjustable wrench		50	
1902	Screw driver		30	



## Special Tools—Continued

Order by these Nos.	Description	No.	Price	Code Word.
1903	Pliers		50	
1904	Spark plug wrench		30	
1917	Double end wrench		30	
1924	3/4" socket wrench		50	
1925	Cylinder head cap screw wrench		50	
1926	Piston pin set screw wrench		40	
1927	Commutator screw driver		05	
1928	Crank shaft bearing nut socket wrench		40	
1929	Fly wheel cap screw wrench		30	
1930X	Valve spring lifter (includes 1938)		75	
1957	Valve grinder		1	00
1933X	Rear wheel puller (includes 1934-5)		1	50
1934	Rear wheel puller cap screw		15	
1935	Rear wheel puller screw		35	
1936X	Cam gear puller (includes 1937)		1	50
1937	Cam gear puller screw		35	
1938	Valve spring lifter hook		30	
1953X	Transmission clutch drum puller (includes 1370)		1	50
1974	Drive shaft and rear axle housing stud nut wrench		40	
1975	Rear axle housing bolt nut wrench		50	
1978	Valve seat reamer		2	50
2318	3/4" T Socket wrench (short)		50	
2319	T screw driver for cam shaft set screw		50	
2320	3/4" T socket wrench		50	
2321	Special L socket wrench for crankshaft bearing bolt nut		50	
2322	3/4" L socket wrench		50	
2323	3/4" open end wrench		35	



**Special Tools—Continued**

Order by these Nos.	Description	Factory No.	Price.	Code Word.
2324	Connecting rod clamp screw wrench		40	
2327	3/8" brace socket wrench (short)		60	
2328	3/8" brace socket wrench (long)		60	
2331	Piston ring squeezer		25	
2332	Magnet screw brace screw driver		50	
2333	Large cam gear lock nut wrench		40	
2335	Cylinder head bolt L socket wrench		50	

**Roadster Body**

4402	Front seat with cushions	40 00	Tuhor
4403	Front seat cushions, per pair	12 00	Tudel
4403 1/4	Front seat cushion—right	6 00	Tudelor
4403 1/2	Front seat cushion—left	6 00	Tudeled
4404	Rumble seat with cushion	10 00	Tudlet
4405	Rumble seat cushion	4 00	Tudhob
4406	Rumble seat lock	80	Tudhag
4408	Front floor rubber matting	3 00	Tudhave
4409	Rear floor rubber matting	3 00	Tudy

**Cotter Pins**

3/32 x 1" Cotter pins	1/8 x 3/4" Cotter pins
3/32 x 3/4" Cotter pins	1/16 x 3/4" Cotter pins
3/32 x 1/2" Cotter pins	1/16 x 1/2" Cotter pins
1/8 x 1" Cotter pins	

Price, each	01
Price, per dozen	05
Price, per gross	23

**Fenders and Running Boards  
1911 Touring Car—56" Tread—Blue**

4800	Front fender—right	1414B	4 00
4801	Front fender—left	1413B	4 00
4802	Rear fender—right	1416C	4 00
4803	Rear fender—left	1415C	4 00
4804	Rear fender iron (right and left)	379	40
4805	Rear fender iron bolt	386	05
4806	Rear fender iron nut	387	03
4807	Rear fender iron lock washer	388	03
4808	Front fender iron bolt (1 1/2")	389	05
4812	Running board—right	2530	1 00
4813	Running board—left	2531	1 00
4814	Running board shield—right	1409B	2 50
4815	Running board shield—left	1408	2 50

Front fender iron (See No. 2939)

**Fenders and Running Boards  
1911 Touring Car—60" Tread—Blue**

Order by these Nos.	Description	Factory No.	Price
4820	Front fender—right	1715B	4 00
4821	Front fender—left	1716B	4 00
4822	Rear fender—right	1749	4 00
4823	Rear fender—left	1748	4 00
4824	Rear fender iron (right and left)	2700	40
4825	Front fender iron (right and left)	1713	1 00
4826	Running board shield—right	1717B	2 50
4827	Running board shield—left	1718B	2 50
	Running board brackets (See No. 3582)		
	Running board truss rods (see No. 3883-4)		

**Fenders and Running Boards  
1911 Runabout—56" Tread—Blue**

4840	Front fender—right	2561	4 00
4841	Front fender—left	2562	4 00
4842	Rear fender—right	2555	4 00
4843	Rear fender—left	2554	4 00
4844	Rear fender iron—right	382	1 50
4845	Rear fender iron—left	381	1 50
4846	Running board—right	2551	60
4847	Running board—left	2552	60
4848	Running board shield—right	2557	2 00
4849	Running board shield—left	2556	2 00

**Fenders and Running Boards  
1911 Runabout—60" Tread—Blue**

4860	Front fender—right	2706	4 00
4861	Front fender—left	2707	4 00
	Front fender-iron (right and left)	See No. 3817	
4863	Rear fender—right	2708	4 00
4864	Rear fender—left	2709	4 00
4865	Rear fender iron—right	2704	1 50
4866	Rear fender iron—left	2705	1 50
4867	Running board shield—right	2703	2 50
4868	Running board shield—left	2710	2 50